Intelix INT-USB3.1CX 4-Port USB 3.1, 100m CAT 6a/7 Point-to-Point Extender System

> **←EXTREME**→ **USB-C**


Quick Start Guide

For complete owners manual scan the following QR code with a smartphone or smart tablet




Before you get started, ensure that all the drivers required for your USB device(s) are installed.

Place extenders where desired and connect the CAT 6a/7 cable to the Link ports on the Local and Remote Extenders.



Max 100m CAT 6a/7 Cable


② Connect the Local Extender to the computer's USB 3 port using the included USB cable.



Power the Local Extender with the included 24V 1A AC adapter and tighten the locking ring.




Power the Remote Extender with the included 24V 2.71A AC adapter and tighten the locking ring.




24V 2.71A AC adapter

Attach USB device(s) to the Remote Extender.



6 Optional: Connect Local and Remote Extender LAN ports to a network or device as necessary.





- * Supports USB 3, 2 and 1
- * True plug and play; no software drivers required
- * Works with all major operation systems: Windows®, macOS™, Linux® and ChromeOS™